

## TRUEVIEW FIRMWARE RELEASE NOTES

VERSION: 2.2.0-21(FFB8A694)

### SUPPORTED PAYLOADS:

The payloads supported by this firmware update;

**TrueView436, TrueView516, TrueView535, TrueView625, TrueView655, TrueView 66o,  
TrueView68o and TrueView72o.**

### FIRMWARE UPDATE DESCRIPTION

- Mobile mapping:
  - Added support for mobile mapping.
  - Added recording pause button to WebUI.
  - Not aligned IMU will turn orange in WebUI for mobile mapping.
  - Added configurable static APX data collection timeout.
- WebUI:
  - Added Settings profile selection to WebUI.
  - Added Pilot Logbook for WebUI.
  - Added settings option to set camera picture interval.
  - Added storage progress bars for USB drives attached directly to LiDAR into WebUI.  
(Only for TV6xx and TV7xx series.)
  - Added LiDAR settings calculator with limits for all supported Riegl models.  
(Only for TV6xx and TV7xx series.)
- Direct access to the internal memory
  - Added ftp access to the internal payload memory. This allows dataset to be downloaded from the payload over WiFi without using the USB Drive.
- Other Changes and Fixes:
  - If USB drive gets full, continue recording to internal storage.
  - Riegl LiDAR drivers updated.
  - APX To4 logging will be programmatically set to "Always" mode.
  - Oversized UDF Frame will be split into smaller frames.
  - Increased GNSS fix quality to improve home position for proximity mode.
  - Geotagging fix: Pictures will be tagged after flight in case of a late APX event.
  - To4 file will be downloaded from APX after each flight. This allows user to access the To4 file from payload internal memory directly after landing.



VERSION: 2.0.1-1 (DC115155)

---

#### SUPPORTED PAYLOADS:

The payloads supported by this firmware update;

**TrueView436, TrueView516, TrueView535, TrueView655, and TrueView 660.**

---

#### FIRMWARE UPDATE DESCRIPTION

- Resolved system crash occurring when the USB drive is full in flight:
  - When recording on external USB drive, recording will continue internally after filling up the USB drive.
- Fixed APX user access through Wi-Fi:
  - APX or LiDAR web page can now be opened using a Wi-Fi connection.
- Added pre-flight data transfer progress bar.
- Added visual recording indicator and additional heartbeat indicator to the Web UI.
  - This prevents early shutdown in case firmware appears to be unresponsive.

VERSION 2.0.0-4 (3DF5369A)

---

#### SUPPORTED PAYLOADS:

The payload supported by this firmware update;

**TrueView436, TrueView516, TrueView535, TrueView655, and TrueView 660.**

---

#### FIRMWARE UPDATE DESCRIPTION

- Recorded data structured for direct processing in LP360.
- Web UI:
  - User interface available through Wi-Fi as a web page running on the payload internal server.
  - This interface provides status overview of the system, troubleshooting information and configuration parameters.
- Data can be collected directly to the USB drive (Only recommended for the TrueView535 payload).
- LiDAR data files (udf) automatically split and are recombined to support large datasets on FAT32 drives. The recommended filesystem format for external drive is FAT32.
- GNSS lever arms can be configured through the Web UI.
- Multiple cameras are supported in the workflow.